Application Guide

--- The operating mode of Reset Button

Contents

Revision History

Updates between document versions are cumulative. Therefore, the latest document version contains all updates made to previous versions.

| Doc Version	Product	Release Data	Details
V1.0	Hongdian Router	2021.07.22	First Release

1 Overview

The reset button of Hongdian router has three operating modes. When there are problems with the router, you can use reset button to recover router OS. Here are explain the three modes of operation.

2 Description

All the operations of all Hongdian routers are the same. Please depend on your device to find the reset button, general labeled "RST" or "RESET".

For example, the reset button of Hongdian Z1 router is on the red arrow.

2.1. Reboot:

Press the reset button with the Ejection Pin. Do not release it and hold it continuously for 5 seconds.

2.2. Restore factory and reboot:

1) Press the reset button with the Ejection Pin. Do not release it and hold it continuously for 10 seconds.

2) Please do not press again after release the reset button within 3 seconds.

2.3. Clear the patch, restore the factory settings and restart:

1) Press the reset button with the Ejection Pin. Do not release it and hold it continuously for more than 5 seconds.

2) Repeat step 1 three times, the interval between two presses is less than 3 seconds.

3) Exception: If the previous two times are completed and the reset button is not pressed again within 3 seconds, the patch is not cleared, and the router is restored factory and reboot.

-END-

HONGDIAN

Create smart things